

Installation Procedure

1. Rotate the foot of the modem and place it upright on a flat, stable surface. Do not place the modem on its side or block the top air vents.
2. Connect the cables as shown in Figure 1.
3. The modem will power up and search for the network signal. As it is searching, the top LEDs will blink sequentially. When the modem is ready to be used, the top LEDs will stop blinking and remain lit.
4. The number of top lights lit indicates the signal strength. Place the modem in a location where the greatest

number of top lights are constantly lit. The ideal placement for this is near a window. The Clearwire modem receives the strongest signal along the flat edge on the opposite side of the cable and Ethernet ports. For optimal service, you should try different positions of the modem to ensure a minimum of 2 lights are lit.

5. In most environments, the modem will function best if it is placed near an exterior wall. The area around the modem should be free of obstructions such as books or electronics.

