

CLEAR SPOT




QUICK START GUIDE

SET IT UP

Step 1:

- Power on your CLEAR Spot® Voyager by pressing and holding the power button (button on the left side "PWR") until you see the Power LED light illuminate. Note: Your CLEAR Spot is partially charged. We recommend that you fully charge your CLEAR Spot prior to activating and using the device.



Step 2:

- When the 4G LED light stops flashing, your CLEAR Spot is ready to connect up to 8 wi-fi-enabled devices. Connect your CLEAR Spot to your PC or MAC® device using the Wi-Fi Network Name (SSID) and Wi-Fi Default Password located on the back of your CLEAR Spot.
- On your PC or Mac® device, open the Wireless Network Connection, select the Wi-Fi Network Name for your CLEAR Spot, and enter the Wi-Fi Password when prompted. The Wi-Fi Network Name can take a couple of minutes to display on the network list.

PC Users: Open Wi-Fi Network Connection



(Example)
Wi-Fi Network
Name (SSID)

Wi-Fi
Network
Connection

Mac® Users: Open Wi-Fi Network Connection



Wi-Fi
Network
Connection

(Example)
Wi-Fi Network
Name (SSID)

Step 3:

- Open your browser and go to any website, where you will be re-directed to the CLEAR® website. Follow the online instructions to quickly complete your account set-up step. That's it! Get online anywhere within CLEAR coverage.

Limited Edition

CLEAR SPOT[®] VOYAGER

QUICK TIPS

- To extend the battery life of your CLEAR Spot[®], limit the number of wi-fi users or reduce your wi-fi range when possible.
- If you are using a wireless device other than a computer, refer to that product's guide for connecting to the wireless network. Be sure to select the CLEAR Spot Wi-Fi Network Name and Wi-Fi Password found on the back of your CLEAR Spot.
- When you initially go online, use your PC or Mac[®] device to complete your CLEAR[®] account set-up and enable your CLEAR 4G internet service.
- You can manage your CLEAR Spot Voyager any time you are connected by typing **http://clearspot** or **http://192.168.1.1** in your browser address bar. Your default password is "admin".

MOST TECHNICAL ISSUES CAN BE RESOLVED BY RESETTING YOUR DEVICE:

- a. Turn on the device by pressing and holding the power button for 3-4 seconds.
- b. Release the power button when the Power LED light turns red.
- c. Once the device is powered on, press and hold the power button for 10 seconds.
- d. Release the power button when the 4G LED light flashes amber. The device will turn off automatically.
- e. Power on the device again. The device will start up with factory default settings.

CUSTOMER SUPPORT AND INFORMATION

- For more detailed product information, go online to the FAQs at clear.com/support/faq, Live Chat Support at clear.com/support, or facebook.com/clear4g.
- If you still have questions, call us at **1-888-888-3113** for live support.
- Para la asistencia en español por favor llame al **1-888-888-3113** y seleccionar español.
- Please read the separate **Important Information** document located under "Help" on your CLEAR[®] Spot homepage for regulatory information, safety information, and other important disclosures.

CLEAR coverage areas are limited. Actual CLEAR network performance may vary and is not guaranteed. CLEAR Spot Voyager device is made in Korea and complies with governing FCC standards. See relevant pages at www.clear.com for additional information. CLEAR, the CLEAR logo and CLEAR Spot are registered trademarks of Clearwire Communications LLC. Mac is a registered trademark of Apple Inc. ©2013 Clear Wireless LLC. All Rights Reserved.